

# BLOWNOUTSPARKPLUG

## TEMPORARY TRANSPORT PLUG FOR FORD 4.6L, 5.4L, and 6.8L ENGINES



### INSTALLATION INSTRUCTIONS

- Remove or relocate any wiring / hoses that may interfere.
- Remove the coils electrical connector and remove coil from vehicle.  
(Push the connector in towards the coil first then push the release on the bottom of the connector and then pull out on the electrical connector)
- Remove fuel injector electrical connector. (see note below)  
(Push the connector in towards the fuel injector first then lightly squeeze the releases on the side(s) of the connector and then pull out on the electrical connector)
- Verify that the bore is free from any foreign objects or liquids.
- Seat plug completely in hole verifying that flat side faces lip on cylinder head.
- Torque the ½” tension nut to 10 foot lbs.

NOTE!!! It is **VERY** important that you unplug the electrical connector to the fuel injector that feeds the affected cylinder. The best way to verify that you are unplugging the correct injector is to count the coils and injectors from the front of the engine.

**Blownoutsparkplug**  
**(805) 886-5213**  
**info@blownoutsparkplug.com**

Buyer, his/her heirs, assigns, legal representatives and attorneys, knowingly and voluntarily release any and all claims, demands, or causes of action, known or unknown, which he/she may have against the seller, his/her successors, assigns, representatives and lessees arising from any injury or illness, including death or disability, incurred in connections with the installation and use of this product.

No warranty is expressed nor implied. Buyer assumes all responsibility for the installation and maintenance of this product. Improper installation, or deliberate misuse shall also release seller, his/her successors, assigns, representatives and lessees from any and all claims, demands, or causes of action, known or unknown arising from any injury or illness, including death or disability, incurred in connections with the installation and use of this product.

The use of this product demonstrates that you have read and fully accept the terms of this agreement. If the owner of this product is unwilling to accept the responsibility and terms of this liability form, the product shall be immediately removed from the vehicle.